

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Aluminium (total)	CE127	Aqua regia digest, ICP-MS		9	mg/kg	Plastic,Glass		180 days
Antimony (total)	CE127	Aqua regia digest, ICP-MS	U	0.2	mg/kg	Plastic,Glass		180 days
Arsenic (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Barium (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Beryllium (total)	CE127	Aqua regia digest, ICP-MS	U	1	mg/kg	Plastic,Glass		180 days
Boron (water soluble)	CE063	Hot water extract, ICP-OES	M	0.5	mg/kg	Plastic,Glass		30 days
Cadmium (total)	CE127	Aqua regia digest, ICP-MS	M	0.2	mg/kg	Plastic,Glass		180 days
Calcium (total)	CE127	Aqua regia digest, ICP-MS		285	mg/kg	Plastic,Glass		180 days
Chromium (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Chromium (hexavalent)	CE146	Acid extraction, Colorimetry		1	mg/kg	Plastic,Glass		30 days
Chromium (III)	CE208	Calculation: Cr (total) - Cr (VI)		1	mg/kg	-		-
Cobalt (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Copper (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Iron (total)	CE127	Aqua regia digest, ICP-MS		38	mg/kg	Plastic,Glass		180 days
Lead (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Magnesium (total)	CE127	Aqua regia digest, ICP-MS		10	mg/kg	Plastic,Glass		180 days
Manganese (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Mercury (total)	CE127	Aqua regia digest, ICP-MS	M	0.5	mg/kg	Plastic,Glass		180 days
Molybdenum (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Nickel (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Potassium (total)	CE127	Aqua regia digest, ICP-MS		20	mg/kg	Plastic,Glass		180 days
Selenium (total)	CE127	Aqua regia digest, ICP-MS	M	0.3	mg/kg	Plastic,Glass		180 days
Sodium (total)	CE127	Aqua regia digest, ICP-MS		22	mg/kg	Plastic,Glass		180 days
Thallium (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Tin (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Vanadium (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Zinc (total)	CE127	Aqua regia digest, ICP-MS	M	5	mg/kg	Plastic,Glass		180 days
Magnesium (extractable)	CE088	Ammonium Nitrate, ICP-MS		1	mg/kg	Plastic,Glass		28 days
Phosphorus (extractable)	CE089	Sodium bicarbonate extraction, ICP-MS		1	mg/kg	Plastic,Glass		28 days
Potassium (extractable)	CE088	Ammonium Nitrate, ICP-MS		1	mg/kg	Plastic,Glass		28 days

TECHNICAL DETAILS SUMMARY

SOILS

Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Inorganics								
pH	CE004	Based on BS 1377, pH Meter	M	-	units	Plastic,Glass		21 days
Ammonia	CE144	KCl extraction, Colorimetry		1	mg/kg N	Plastic,Glass		28 days
Ammoniacal Nitrogen	CE144	KCl extraction, Colorimetry		1	µg/l NH ₄	Plastic,Glass		28 days
Electrical conductivity	CE007	Conductivity Meter	U	10	µS/cm	Plastic,Glass		28 days
Magnesium (2:1 water soluble)	CE061	Aqueous extraction, ICP-OES		1	mg/l	Plastic,Glass		28 days
Chloride (2:1 water soluble)	CE193	Aqueous extraction, IC-COND	U	1	mg/l	Plastic,Glass		28 days
Fluoride (2:1 water soluble)	CE193	Aqueous extraction, IC-COND		0.1	mg/l	Plastic,Glass		28 days
Nitrate (2:1 water soluble)	CE193	Aqueous extraction, IC-COND	U	1	mg/l	Plastic,Glass		28 days
Nitrite (2:1 water soluble)	CE193	Aqueous extraction, IC-COND		1	mg/l	Plastic,Glass		28 days
Phosphate (2:1 water soluble)	CE193	Aqueous extraction, IC-COND		1	mg/l	Plastic,Glass		28 days
Sulphate (2:1 water soluble)	CE193	Aqueous extraction, IC-COND	U	10	mg/l	Plastic,Glass		28 days
Sulphate (2:1 water soluble)	CE061	Aqueous extraction, ICP-OES	M	10	mg/l	Plastic,Glass		28 days
Sulphate (total)	CE062	Acid extraction, ICP-OES	M	100	mg/kg	Plastic,Glass		28 days
Sulphur (free)	CE034	Solvent extraction, HPLC	M	10	mg/kg	Plastic,Glass		28 days
Sulphur (total)	CE127	Acid extraction, ICP-MS		100	mg/kg	Plastic,Glass		28 days
Sulphide	CE079	Extraction, Continuous Flow Colorimetry		10	mg/kg	Plastic,Glass		7 days
Cyanide (free)	CE077	Extraction, Continuous Flow Colorimetry		1	mg/kg	Plastic,Glass		14 days
Cyanide (complex)	CE077	Calculation: CN (total) - CN (free)		1	mg/kg	Plastic,Glass		14 days
Cyanide (total)	CE077	Extraction, Continuous Flow Colorimetry		1	mg/kg	Plastic,Glass		14 days
Thiocyanate	CE145	Weak acid extraction, Colorimetry	M	1	mg/kg	Plastic,Glass		14 days
Phenols (total)	CE078	Extraction, Continuous Flow Colorimetry		0.5	mg/kg	Plastic,Glass		28 days
Total Carbon	CE072	Carbon Analyser		0.1	% w/w	Plastic,Glass		28 days
Total Organic Carbon	CE072	Removal of IC, Carbon Analyser	M	0.1	% w/w	Plastic,Glass		28 days
Estimate of OMC (calculated from TOC)	CE072	OMC calculated from TOC	M	0.1	% w/w	Plastic,Glass		28 days
Estimate of FOC (calculated from TOC)	CE072	FOC calculated from TOC		0.001	-	Plastic,Glass		28 days
Inorganic Carbon (by difference)	CE072	Carbon Analyser		0.1	% w/w	Plastic,Glass		28 days
Carbonate (by difference)	CE072	Carbon Analyser, calculation TC-TOC		0.1	% w/w	Plastic,Glass		28 days
Loss On Ignition at 440°C	CE006	Based on BS 1377, Gravimetry	U	0.1	% w/w	Plastic,Glass		28 days
Calorific value	CE069	Combustion, Carbon analyser		100	kJ/kg	Plastic,Glass		28 days
Nitrogen (total)	CE198	Combustion, Nitrogen analyser		100	kJ/kg	Plastic,Glass		28 days
Carbon:Nitrogen ratio	CE222	Calculation: TOC/Nitrogen (total)		0.1	-	Plastic,Glass		28 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PAHs								
Naphthalene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Acenaphthylene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Acenaphthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Fluorene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Phenanthrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Anthracene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Fluoranthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Pyrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(a)anthracene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Chrysene	CE087	Solvent extraction, GC-MS	M	0.03	mg/kg	Glass		*14 days
Benzo(b)fluoranthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(k)fluoranthene	CE087	Solvent extraction, GC-MS	M	0.03	mg/kg	Glass		*14 days
Benzo(a)pyrene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Indeno(123cd)pyrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Dibenz(ah)anthracene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(ghi)perylene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
PAH (total of USEPA 16)	CE087	Solvent extraction, GC-MS		0.34	mg/kg	Glass		*14 days
Benzo(j)fluoranthene	CE087	Solvent extraction, GC-MS		0.02	mg/kg	Glass		*14 days
PAH (total of OIL 8)	CE087	Solvent extraction, GC-MS		0.18	mg/kg	Glass		*14 days
Coronene	CE087	Solvent extraction, GC-MS		0.02	mg/kg	Glass		*14 days
PAH (total of 17)	CE087	Solvent extraction, GC-MS		0.36	mg/kg	Glass		*14 days
BTEX & MTBE								
MTBE	CE192	Headspace GC-FID	U	0.02	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Benzene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Toluene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Ethylbenzene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
m & p-Xylene	CE192	Headspace GC-FID	U	0.02	mg/kg	VOC jar	Fill to brim, no headspace	14 days
o-Xylene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
BTEX (total)	CE192	Headspace GC-FID		0.06	mg/kg	VOC jar	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Banded								
VPH (>C5-C10)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH (>C5-C7)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH (>C7-C8)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH (>C8-C10)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
EPH (>C10-C35)	CE033	Solvent extraction, GC-FID		7	mg/kg	Glass		*14 days
EPH (>C10-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C44)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C16)	CE033	Solvent extraction, GC-FID		7	mg/kg	Glass		*14 days
EPH (>C16-C40)	CE033	Solvent extraction, GC-FID		6	mg/kg	Glass		*14 days
EPH (>C10-C20)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C20-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C21)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C21-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C25)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C25-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C28)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C28-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C10-C12)	CE033	Solvent extraction, GC-FID	M	4	mg/kg	Glass		*14 days
EPH (>C12-C16)	CE033	Solvent extraction, GC-FID	M	4	mg/kg	Glass		*14 days
EPH (>C16-C21)	CE033	Solvent extraction, GC-FID	M	4	mg/kg	Glass		*14 days
EPH (>C16-C35)	CE033	Solvent extraction, GC-FID	M	4	mg/kg	Glass		*14 days
EPH (>C21-C35)	CE033	Solvent extraction, GC-FID	M	6	mg/kg	Glass		*14 days
EPH (>C35-C40)	CE033	Solvent extraction, GC-FID	U	10	mg/kg	Glass		*14 days
EPH (>C35-C44)	CE033	Solvent extraction, GC-FID	U	10	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Aliphatic/Aromatic								
VPH Aliphatic (>C5-C6)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH Aliphatic (>C6-C8)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH Aliphatic (>C8-C10)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC5-EC7)	CE067	Headspace GC-FID		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC7-EC8)	CE067	Headspace GC-FID		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC8-EC10)	CE067	Headspace GC-FID		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
EPH Aliphatic (>C10-C12)	CE068	Solvent extraction, GC-FID		5	mg/kg	Glass		*14 days
EPH Aliphatic (>C12-C16)	CE068	Solvent extraction, GC-FID		5	mg/kg	Glass		*14 days
EPH Aliphatic (>C16-C35)	CE068	Solvent extraction, GC-FID		15	mg/kg	Glass		*14 days
EPH Aliphatic (>C35-C44)	CE068	Solvent extraction, GC-FID		3	mg/kg	Glass		*14 days
EPH Aromatic (>EC10-EC12)	CE068	Solvent extraction, GC-FID		6	mg/kg	Glass		*14 days
EPH Aromatic (>EC12-EC16)	CE068	Solvent extraction, GC-FID		7	mg/kg	Glass		*14 days
EPH Aromatic (>EC16-EC21)	CE068	Solvent extraction, GC-FID		4	mg/kg	Glass		*14 days
EPH Aromatic (>EC21-EC35)	CE068	Solvent extraction, GC-FID		8	mg/kg	Glass		*14 days
EPH Aromatic (>EC35-EC44)	CE068	Solvent extraction, GC-FID		3	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds								
MTBE	CE192	Headspace GC-FID	U	0.02	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Benzene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Toluene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Ethylbenzene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
m & p-Xylene	CE192	Headspace GC-FID	U	0.02	mg/kg	VOC jar	Fill to brim, no headspace	14 days
o-Xylene	CE192	Headspace GC-FID	U	0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Dichlorodifluoromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Chloromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Vinyl chloride	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Bromomethane	CE174	Headspace GC-MS		0.03	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Chloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Trichlorofluoromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1-Dichloroethene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Trans-1,2-Dichloroethene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
MTBE	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1-Dichloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
2,2-Dichloropropane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Cis-1,2-Dichloroethene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Bromochloromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Chloroform	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1,1-Trichloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Carbon tetrachloride	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1-Dichloro-1-propene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Benzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2-Dichloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Trichloroethene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2-Dichloropropane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Dibromomethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Bromodichloromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
cis-1,3-Dichloro-1-propene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Toluene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
trans-1,3-Dichloro-1-propene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1,2-Trichloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds (cont)								
Tetrachloroethene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,3-Dichloropropane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Dibromochloromethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2-Dibromoethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Chlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1,1,2-Tetrachloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Styrene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Tribromomethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Isopropylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Bromobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,1,2,2-Tetrachloroethane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Ethylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
m & p-Xylene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
o-Xylene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2,3-Trichloropropane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Propylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
2-Chlorotoluene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
4-Chlorotoluene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,3,5-Trimethylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
tert-Butylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2,4-Trimethylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
sec-Butylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,3-Dichlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
4-Isopropyltoluene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,4-Dichlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2-Dichlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Butylbenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2-Dibromo-3-chloropropane	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2,4-Trichlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
Hexachloro-1,3-butadiene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
1,2,3-Trichlorobenzene	CE174	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
VOC Tentatively Identified Compounds	CE189	Headspace GC-MS		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds								
Naphthalene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Acenaphthylene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Acenaphthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Fluorene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Phenanthrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Anthracene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Fluoranthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Pyrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(a)anthracene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Chrysene	CE087	Solvent extraction, GC-MS	M	0.03	mg/kg	Glass		*14 days
Benzo(b)fluoranthene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(k)fluoranthene	CE087	Solvent extraction, GC-MS	M	0.03	mg/kg	Glass		*14 days
Benzo(a)pyrene	CE087	Solvent extraction, GC-MS	U	0.02	mg/kg	Glass		*14 days
Indeno(123cd)pyrene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Dibenz(ah)anthracene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
Benzo(ghi)perylene	CE087	Solvent extraction, GC-MS	M	0.02	mg/kg	Glass		*14 days
N-Nitrosodimethylamine	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Phenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Bis(2-chloroethyl)ether	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Chlorophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
1,3-Dichlorobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
1,4-Dichlorobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Methylphenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
1,2-Dichlorobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Bis(2-chloroisopropyl)ether	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
3&4-Methylphenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
N-Nitrosodi-n-propylamine	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Hexachloroethane	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Nitrobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Isophorone	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,4-Dimethylphenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Nitrophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Bis(2-chloroethoxy)methane	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds (cont)								
2,4-Dichlorophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
1,2,4-Trichlorobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Chloroaniline	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Hexachlorobutadiene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Chloro-3-methylphenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Methylnaphthalene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
1-Methylnaphthalene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Hexachlorocyclopentadiene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,4,6-Trichlorophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,4,5-Trichlorophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Chloronaphthalene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Nitroaniline	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Dimethyl phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,6-Dinitrotoluene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
3-Nitroaniline	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,4-Dinitrophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Nitrophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2,4-Dinitrotoluene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Dibenzofuran	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Diethyl phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Chlorophenylphenyl ether	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Nitroaniline	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
2-Methyl-4,6-dinitrophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Azobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
4-Bromophenylphenyl ether	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Hexachlorobenzene	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Pentachlorophenol	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Carbazole	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Di-n-butyl phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Butylbenzyl phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Bis(2-ethylhexyl)phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Di-n-octyl phthalate	CE189	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
SVOC Tentatively Identified Compounds	CE189	Solvent extraction, GC-MS		1	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Phenols (speciated)								
Dimethylphenols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Methylphenols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Naphthols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Phenol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Trimethylphenol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Catechol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
Resorcinol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		28 days
PCB (ICES 7)								
PCB Congener 28	CE137	Solvent extraction, GC-MS	M	0.004	mg/kg	Glass		*14 days
PCB Congener 52	CE137	Solvent extraction, GC-MS	M	0.004	mg/kg	Glass		*14 days
PCB Congener 101	CE137	Solvent extraction, GC-MS	M	0.008	mg/kg	Glass		*14 days
PCB Congener 118	CE137	Solvent extraction, GC-MS	M	0.006	mg/kg	Glass		*14 days
PCB Congener 138	CE137	Solvent extraction, GC-MS	M	0.006	mg/kg	Glass		*14 days
PCB Congener 153	CE137	Solvent extraction, GC-MS	M	0.009	mg/kg	Glass		*14 days
PCB Congener 180	CE137	Solvent extraction, GC-MS	M	0.008	mg/kg	Glass		*14 days
PCB (total of ICES 7)	CE137	Solvent extraction, GC-MS	M	0.045	mg/kg	Glass		*14 days
PCB (WHO 12)								
PCB Congener 77	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 81	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 105	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 114	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 118	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 123	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 126	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 156	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 157	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 167	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 169	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB Congener 189	CE181	Solvent extraction, GC-MS		0.006	mg/kg	Glass		*14 days
PCB (total of WHO 12)	CE181	Solvent extraction, GC-MS		0.072	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS

Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides								
2,4'-DDD (O,P'-DDD)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4,4'-DDD (P,P'-DDD)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,4'-DDE (O,P'-DDE)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4,4'-DDE (P,P'-DDE)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,4'-DDT (O,P'-DDT)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4,4'-DDT (P,P'-DDT)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4,4'-TDE (P,P'-TDE)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,6-Dichlorobenzonitrile	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4,4'-Dichlorobenzophenone	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Aldrin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Alpha-HCH	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Benfluralin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Beta-HCH	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Biphenyl	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chlorfenson	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chloroneb	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chlorothalonil	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
cis-Chlordane	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
cis-Nonachlor	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Delta-HCH	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dichlofluanid	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dicloran	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dicofol	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dieldrin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Diphenylamine	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endosulphan A	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endosulphan B	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endosulphan ether	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endosulphan sulphate	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endrin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endrin aldehyde	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Endrin ketone	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS

Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides (cont)								
Ethalfuralin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Fenson	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Gamma-HCH (Lindane)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
HCB	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Heptachlor	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Heptachlor epoxide	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Isodrin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Isopropalin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Isopropalin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Methoxychlor	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Methoxychlor olefin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Mirex	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Nitralin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Nitrofen	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Oxyfluorfen	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pendimethalin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachloroaniline	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachloroanisole	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachlorobenzene	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachlorobenzonitrile	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachloronitrobenzene (Quintozene)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachlorothioanisole	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Prodiamine	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Profluralin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Tetrachloronitrobenzene (Tecnazene)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Tetradifon	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
THPI (Tetrahydrophthalimide)	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Tolyfluanid	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
trans-Chordane	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
trans-Nonachlor	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Trifluralin	CE112	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides								
Acephate	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Azinphos ethyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Azinphos methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Bromophos ethyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chlorpyrifos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chlorpyrifos methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Coumaphos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Demeton-S-methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Diazinon	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dichlorvos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dimethoate	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Disulfoton	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
EPN	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Ethion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Ethoprophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Famphur	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Fenclorphos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Fenitrothion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Fensulfothion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Isazophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Malathion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Merphos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Methamidophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Methidathion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Methomyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Monocrotophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Naled	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Omethoate	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Parathion	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Parathion methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Phorate	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Phosalone	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides (cont)								
Phosmet	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pirimiphos ethyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pirimiphos methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Profenofos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Prothiophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pyraclofos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pyrazophos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pyridaphention	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Quinalphos	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Sulfotep	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Thiofanox	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Thionazin	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Tolclofos-methyl	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Trichlorfon	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Trichlorfon	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Triethyl thiophosphate	CE113	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Acid herbicides								
2,4-D	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,4,5-T	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,4-DB	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Acifluorfen	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Bentazon	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Bromoxynil	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Chloramben	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dalapon	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dicamba	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
3,5-Dichlorobenzoic acid (DBA)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dichlorprop (2,4-DP)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Dinoseb (DNBP)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,4,5-TP	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Fluroxypyr	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Imazapyr	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Ioxynil	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
MCPA	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
MCPP	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Mecoprop (MCP)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Pentachlorophenol	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Picloram	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
2,3,6-TBA	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
4-Chlorophenoxyacetic acid (4-CPA)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Phenoxyacetic acid	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Phenoxybutyric acid	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Phenoxypropionic acid	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Propanil (DCPA)	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
DCPA diacid	CE114	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

SOILS



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organonitrogen pesticides								
Ametryn	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Atraton	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Atrazine	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Prometon	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Prometryn	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Propazine	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Secbumbeton	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Simazine	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Simetryn	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Terbutylazine	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Terbutryn	CE209	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Subcontracted testing								
Asbestos (qualitative)	\$	HSG 248, Microscopy	U	-	-	-	-	-
Asbestos (quantitative)	\$	Gravimetry	U	0.001	% w/w	-	-	-
Dibutyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days
Tributyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days
Triphenyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited
\$ = Subcontracted

*days for extraction; 40 days after extraction for analysis.

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Preparation								
Leachate preparation (EA)	CE002	L:S 10:1		-	-	-	-	-
Leachate preparation (single-stage)	CE002	BS12457-1 or BS12457-2		-	-	-	-	-
Leachate preparation (two-stage)	CE002	BS12457-3		-	-	-	-	-

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

\$ = Subcontracted

*days for extraction; 40 days after extraction for analysis.

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Aluminium (dissolved)	CE128	ICP-MS	U	4	µg/l Al	Plastic		180 days
Antimony (dissolved)	CE128	ICP-MS	U	0.1	µg/l Sb	Plastic		180 days
Arsenic (dissolved)	CE128	ICP-MS	U	0.06	µg/l As	Plastic		180 days
Barium (dissolved)	CE128	ICP-MS	U	0.6	µg/l Ba	Plastic		180 days
Beryllium (dissolved)	CE128	ICP-MS	U	0.06	µg/l Be	Plastic		180 days
Boron (dissolved)	CE128	ICP-MS	U	8	µg/l B	Plastic		180 days
Cadmium (dissolved)	CE128	ICP-MS	U	0.07	µg/l Cd	Plastic		180 days
Calcium (dissolved)	CE128	ICP-MS	U	0.04	mg/l Ca	Plastic		180 days
Chromium (dissolved)	CE128	ICP-MS	U	0.2	µg/l Cr	Plastic		180 days
Chromium (hexavalent)	CE050	Colorimetry	U	10	µg/l CrVI	Plastic		30 days
Chromium (III)	CE207	Calculation: Cr (total) - Cr (VI)		10	µg/l CrIII	-		-
Cobalt (dissolved)	CE128	ICP-MS	U	0.2	µg/l Co	Plastic		180 days
Copper (dissolved)	CE128	ICP-MS	U	0.4	µg/l Cu	Plastic		180 days
Iron (dissolved)	CE128	ICP-MS	U	3	µg/l Fe	Plastic		180 days
Lead (dissolved)	CE128	ICP-MS	U	0.2	µg/l Pb	Plastic		180 days
Magnesium (dissolved)	CE128	ICP-MS	U	0.01	mg/l Mg	Plastic		180 days
Manganese (dissolved)	CE128	ICP-MS	U	0.4	µg/l Mn	Plastic		180 days
Mercury (dissolved)	CE128	ICP-MS	U	0.008	µg/l Hg	Plastic		180 days
Molybdenum (dissolved)	CE128	ICP-MS	U	0.3	µg/l Mo	Plastic		180 days
Nickel (dissolved)	CE128	ICP-MS	U	0.5	µg/l Ni	Plastic		180 days
Phosphorus (dissolved)	CE128	ICP-MS	U	0.02	µg/l P	Plastic		180 days
Potassium (dissolved)	CE128	ICP-MS	U	0.03	mg/l K	Plastic		180 days
Selenium (dissolved)	CE128	ICP-MS	U	0.07	µg/l Se	Plastic		180 days
Silver (dissolved)	CE128	ICP-MS		0.2	µg/l Ag	Plastic		180 days
Sodium (dissolved)	CE128	ICP-MS	U	0.6	mg/l Na	Plastic		180 days
Strontium (dissolved)	CE128	ICP-MS	U	0.4	µg/l Sr	Plastic		180 days
Thallium (dissolved)	CE128	ICP-MS		16	µg/l Tl	Plastic		180 days
Tin (dissolved)	CE128	ICP-MS	U	0.5	µg/l Sn	Plastic		180 days
Titanium (dissolved)	CE128	ICP-MS		2	µg/l Ti	Plastic		180 days
Vanadium (dissolved)	CE128	ICP-MS	U	0.3	µg/l V	Plastic		180 days
Zinc (dissolved)	CE128	ICP-MS	U	1	µg/l Zn	Plastic		180 days
Hardness (by calculation)	CE128	ICP-MS		1	mg/l CaCO ₃	Plastic		180 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Inorganics								
pH	CE213	Based on BS 1377, pH Meter	U	0.1	units	Plastic,Glass		21 days
Electrical conductivity	CE214	Conductivity Meter	U	10	µS/cm	Plastic,Glass		28 days
Ammonia	CE012	Colorimetry	U	10	µg/l N	Plastic,Glass		28 days
Ammoniacal Nitrogen	CE012	Colorimetry	U	10	µg/l NH ₄	Plastic,Glass		28 days
Bromate	CE219	Ion Chromatography		0.7	mg/l BrO ₃	Plastic,Glass		28 days
Bromide	CE049	Ion Chromatography	U	0.4	mg/l Br	Plastic,Glass		28 days
Chloride	CE049	Ion Chromatography	U	0.5	mg/l Cl	Plastic,Glass		28 days
Fluoride	CE049	Ion Chromatography	U	0.1	mg/l F	Plastic,Glass		28 days
Nitrate	CE049	Ion Chromatography	U	0.3	mg/l NO ₃	Plastic,Glass		28 days
Nitrite	CE049	Ion Chromatography	U	0.2	mg/l NO ₂	Plastic,Glass		28 days
Total Oxidised Nitrogen (as N)	CE049	Sum of Nitrate and Nitrite		0.3	mg/l N	Plastic,Glass		28 days
Phosphate	CE049	Ion Chromatography	U	0.3	mg/l PO ₄	Plastic,Glass		28 days
Sulphate	CE049	Ion Chromatography	U	1.7	mg/l SO ₄	Plastic,Glass		28 days
Sulphur (free)	CE034	Solvent extraction, HPLC		5	mg/l S	Plastic,Glass		28 days
Sulphur (dissolved)	CE128	ICP-MS	U	0.2	mg/l S	Plastic,Glass		28 days
Sulphide	CE220	Continuous Flow Colorimetry		0.1	µg/l S ₂ -	Plastic,Glass		7 days
Cyanide (free)	CE147	Continuous Flow Colorimetry		20	µg/l CN	Plastic,Glass		14 days
Cyanide (complex)	CE147	Calculation: CN (total) - CN (free)		20	µg/l CN	Plastic,Glass		14 days
Cyanide (total)	CE147	Continuous Flow Colorimetry		20	µg/l CN	Plastic,Glass		14 days
Thiocyanate	CE014	Colorimetry		200	µg/l SCN	Plastic,Glass		14 days
Phenols (total)	CE148	Continuous Flow Colorimetry		10	µg/l PhOH	Plastic,Glass		28 days
Alkalinity (settled)	CE035	Titrimetry	U	2	mg/l CaCO ₃	Plastic,Glass		28 days
Total dissolved solids	CE039	TDS meter		10	mg/l TDS	Plastic,Glass		28 days
Chemical Oxygen Demand (filtered)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass		28 days
Dissolved Organic Carbon	CE071	Filtration, TOC analyser		5	mg/l C	Plastic,Glass		28 days
Oil & Grease	CE030	Solvent extraction, Gravimetry		1	mg/l	Glass		28 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PAHs								
Naphthalene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Acenaphthylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Acenaphthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Fluorene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Phenanthrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(a)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Chrysene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(b)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(k)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(a)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Indeno(123cd)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Dibenz(ah)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(ghi)perylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
PAH (total of USEPA 16)	CE051	Solvent extraction, GC-MS		1.6	µg/l	Glass		*14 days
Benzo(j)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
PAH (total of OIL 8)	CE051	Solvent extraction, GC-MS		0.8	µg/l	Glass		*14 days
Coronene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
PAH (total of 17)	CE051	Solvent extraction, GC-MS		1.7	µg/l	Glass		*14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PAHs (low level)								
Naphthalene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Acenaphthylene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Acenaphthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Fluorene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Phenanthrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Benzo(a)anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Chrysene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Benzo(b)fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Benzo(k)fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Benzo(a)pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Indeno(123cd)pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Dibenz(ah)anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
Benzo(ghi)perylene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		*14 days
PAH (total of USEPA 16)	CE196	Solvent extraction, GC-MS (low level)		0.16	µg/l	Glass		*14 days
BTEX & MTBE								
MTBE	CE057	Headspace GC-FID	U	2	µg/l	VOC jar	Fill to brim, no headspace	14 days
Benzene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
Toluene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
Ethylbenzene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
m & p-Xylene	CE057	Headspace GC-FID	U	2	µg/l	VOC jar	Fill to brim, no headspace	14 days
o-Xylene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
BTEX (total)	CE057	Headspace GC-FID		6	µg/l	VOC jar	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key:

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Banded								
VPH (>C5-C10)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH (>C5-C7)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH (>C7-C8)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH (>C8-C10)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
EPH (>C10-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C44)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C16)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C16-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C20)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C20-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C21)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C21-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C25)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C25-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C28)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C28-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		*14 days
EPH (>C10-C12)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C12-C16)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C16-C21)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C16-C35)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C21-C35)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C35-C40)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH (>C35-C44)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key:

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Aliphatic/Aromatic								
VPH Aliphatic (>C5-C6)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH Aliphatic (>C6-C8)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH Aliphatic (>C8-C10)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC5-EC7)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC7-EC8)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
VPH Aromatic (>EC8-EC10)	CE175	Headspace GC-FID		1	µg/l	VOC jar	Fill to brim, no headspace	14 days
EPH Aliphatic (>C10-C12)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aliphatic (>C12-C16)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aliphatic (>C16-C21)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aliphatic (>C16-C35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aliphatic (>C21-C35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aliphatic (>C35-C44)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aromatic (>EC10-EC12)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aromatic (>EC12-EC16)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aromatic (>EC16-EC21)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aromatic (>EC21-EC35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days
EPH Aromatic (>EC35-EC44)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		*14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds								
MTBE	CE057	Headspace GC-FID	U	2	µg/l	VOC jar	Fill to brim, no headspace	14 days
Benzene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
Toluene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
Ethylbenzene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
m & p-Xylene	CE057	Headspace GC-FID	U	2	µg/l	VOC jar	Fill to brim, no headspace	14 days
o-Xylene	CE057	Headspace GC-FID	U	1	µg/l	VOC jar	Fill to brim, no headspace	14 days
Dichlorodifluoromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Chloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Vinyl chloride	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Bromomethane	CE066	Headspace GC-MS		3	µg/l	Vial	Fill to brim, no headspace	14 days
Chloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Trichlorofluoromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Trans-1,2-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1-Dichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
2,2-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Cis-1,2-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Bromochloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Chloroform	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1,1-Trichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Carbon tetrachloride	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2-Dichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Trichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Dibromomethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Bromodichloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
cis-1,3-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
trans-1,3-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1,2-Trichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds (cont)								
Tetrachloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,3-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Dibromochloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2-Dibromoethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Chlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1,1,2-Tetrachloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Styrene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Tribromomethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Isopropylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Bromobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,1,1,2,2-Tetrachloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2,3-Trichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Propylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
2-Chlorotoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
4-Chlorotoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,3,5-Trimethylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
tert-Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2,4-Trimethylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
sec-Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,3-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
4-Isopropyltoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,4-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2-Dibromo-3-chloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2,4-Trichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
Hexachloro-1,3-butadiene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
1,2,3-Trichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	14 days
VOC Tentatively Identified Compounds	CE066	Headspace GC-MS		10	µg/l	Vial	Fill to brim, no headspace	14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds								
Naphthalene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Acenaphthylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Acenaphthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Fluorene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Phenanthrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(a)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Chrysene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(b)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(k)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(a)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Indeno(123cd)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Dibenz(ah)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
Benzo(ghi)perylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		*14 days
N-Nitrosodimethylamine	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Phenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Bis(2-chloroethyl)ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Chlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
1,3-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
1,4-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
1,2-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Bis(2-chloroisopropyl)ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
3&4-Methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
N-Nitrosodi-n-propylamine	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Hexachloroethane	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Nitrobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Isophorone	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,4-Dimethylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Nitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Bis(2-chloroethoxy)methane	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds (cont)								
2,4-Dichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
1,2,4-Trichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Chloroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Hexachlorobutadiene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Chloro-3-methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Methylnaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
1-Methylnaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Hexachlorocyclopentadiene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,4,6-Trichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,4,5-Trichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Chloronaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Dimethyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,6-Dinitrotoluene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
3-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,4-Dinitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Nitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2,4-Dinitrotoluene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Dibenzofuran	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Diethyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Chlorophenylphenyl ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
2-Methyl-4,6-dinitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Azobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
4-Bromophenylphenyl ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Hexachlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Pentachlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Carbazole	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Di-n-butyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Butylbenzyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Bis(2-ethylhexyl)phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
Di-n-octyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
SVOC Tentatively Identified Compounds	CE065	Solvent extraction, GC-MS		1	µg/l	Glass		14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Phenols (speciated)								
Dimethylphenols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Methylphenols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Naphthols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Phenol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Trimethylphenol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Catechol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
Resorcinol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		28 days
PCB (ICES 7)								
PCB Congener 28	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 52	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 101	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 118	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 138	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 153	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 180	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB (total of ICES 7)	CE070	Solvent extraction, GC-MS		0.7	µg/l	Glass		14 days
PCB (WHO 12)								
PCB Congener 77	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 81	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 105	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 114	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 118	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 123	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 126	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 156	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 157	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 167	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 169	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB Congener 189	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		14 days
PCB (total of WHO 12)	CE187	Solvent extraction, GC-MS		1.2	µg/l	Glass		14 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides								
2,4'-DDD (O,P'-DDD)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDD (P,P'-DDD)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4'-DDE (O,P'-DDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDE (P,P'-DDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4'-DDT (O,P'-DDT)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDT (P,P'-DDT)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-TDE (P,P'-TDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,6-Dichlorobenzonitrile	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-Dichlorobenzophenone	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Aldrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Alpha-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Benfluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Beta-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Biphenyl	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorfenson	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chloroneb	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorothalonil	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
cis-Chlordane	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
cis-Nonachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Delta-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlofluanid	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicloran	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicofol	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dieldrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Diphenylamine	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan A	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan B	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan ether	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan sulphate	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin aldehyde	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin ketone	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides (cont)								
Ethalfuralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenson	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Gamma-HCH (Lindane)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
HCB	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Heptachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Heptachlor epoxide	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isodrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isopropalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isopropalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methoxychlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methoxychlor olefin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Mirex	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Nitralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Nitrofen	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Oxyfluorfen	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pendimethalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloroaniline	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloroanisole	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorobenzene	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorobenzonitrile	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloronitrobenzene (Quintozene)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorothioanisole	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prodiamine	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Profluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tetrachloronitrobenzene (Tecnazene)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tetradifon	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
THPI (Tetrahydrophthalimide)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tolyfluamid	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
trans-Chordane	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
trans-Nonachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trifluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides								
Acephate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Azinphos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Azinphos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bromophos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorpyrifos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorpyrifos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Coumaphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Demeton-S-methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Diazinon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlorvos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dimethoate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Disulfoton	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
EPN	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ethion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ethoprophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Famphur	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenchlorphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenitrothion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fensulfothion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isazophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Malathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Merphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methamidophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methidathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methomyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Monocrotophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Naled	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Omethoate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Parathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Parathion methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phorate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

\$ = Subcontracted

*days for extraction; 40 days after extraction for analysis.

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides (cont)								
Phosalone	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phosmet	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pirimiphos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pirimiphos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Profenofos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prothiophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyraclofos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyrazophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyridaphention	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Quinalphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Sulfotep	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Thiofanox	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Thionazin	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tolclofos-methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trichlorfon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trichlorfon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Triethyl thiophosphate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES

Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

\$ = Subcontracted

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Acid herbicides								
2,4-D	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4,5-T	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4-DB	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Acifluorfen	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bentazon	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bromoxynil	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chloramben	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dalapon	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicamba	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
3,5-Dichlorobenzoic acid (DBA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlorprop (2,4-DP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dinoseb (DNBP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4,5-TP	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fluroxypyr	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Imazapyr	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ioxynil	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
MCPA	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
MCPP	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Mecoprop (MCP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorophenol	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Picloram	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,3,6-TBA	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4-Chlorophenoxyacetic acid (4-CPA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxyacetic acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxybutyric acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxypropionic acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Propanil (DCPA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
DCPA diacid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

PREPARED LEACHATES



Further method details are available on request.

Holding times for prepared leachates are based on those for soil.

Key: U = UKAS accredited
\$ = Subcontracted

*days for extraction; 40 days after extraction for analysis.

PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organonitrogen pesticides								
Ametryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Atraton	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Atrazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prometon	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prometryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Propazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Secbumbeton	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Simazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Simetryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Terbutylazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Terbutryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Subcontracted testing								
Dibutyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days
Tributyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days
Triphenyl tin	\$	Extraction, GC-MS		0.05	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Aluminium (dissolved)	CE128	Filtration, ICP-MS	U	4	µg/l Al	Plastic		4 days
Antimony (dissolved)	CE128	Filtration, ICP-MS	U	0.1	µg/l Sb	Plastic		20 days
Arsenic (dissolved)	CE128	Filtration, ICP-MS	U	0.06	µg/l As	Plastic		28 days
Barium (dissolved)	CE128	Filtration, ICP-MS	U	0.6	µg/l Ba	Plastic		28 days
Beryllium (dissolved)	CE128	Filtration, ICP-MS	U	0.06	µg/l Be	Plastic		5 days
Boron (dissolved)	CE128	Filtration, ICP-MS	U	8	µg/l B	Plastic		4 days
Cadmium (dissolved)	CE128	Filtration, ICP-MS	U	0.07	µg/l Cd	Plastic		13 days
Calcium (dissolved)	CE128	Filtration, ICP-MS	U	0.04	mg/l Ca	Plastic		28 days
Chromium (dissolved)	CE128	Filtration, ICP-MS	U	0.2	µg/l Cr	Plastic		7 days
Chromium (hexavalent)	CE050	Colorimetry	U	10	µg/l CrVI	Plastic		4 days
Chromium (hexavalent)	CE050	Colorimetry	U	10	µg/l CrVI	Plastic	NH4SO4/OH	28 days
Chromium (III)	CE207	Calculation: Cr (total) - Cr (VI)		10	µg/l CrIII	-	-	-
Cobalt (dissolved)	CE128	Filtration, ICP-MS	U	0.2	µg/l Co	Plastic		7 days
Copper (dissolved)	CE128	Filtration, ICP-MS	U	0.4	µg/l Cu	Plastic		5 days
Iron (dissolved)	CE128	Filtration, ICP-MS	U	3	µg/l Fe	Plastic		3 days
Lead (dissolved)	CE128	Filtration, ICP-MS	U	0.2	µg/l Pb	Plastic		12 days
Magnesium (dissolved)	CE128	Filtration, ICP-MS	U	0.01	mg/l Mg	Plastic		20 days
Manganese (dissolved)	CE128	Filtration, ICP-MS	U	0.4	µg/l Mn	Plastic		5 days
Mercury (dissolved)	CE128	Filtration, ICP-MS	U	0.008	µg/l Hg	Plastic		3 days
Molybdenum (dissolved)	CE128	Filtration, ICP-MS	U	0.3	µg/l Mo	Plastic		8 days
Nickel (dissolved)	CE128	Filtration, ICP-MS	U	0.5	µg/l Ni	Plastic		5 days
Phosphorus (dissolved)	CE128	Filtration, ICP-MS	U	0.02	µg/l P	Plastic		9 days
Potassium (dissolved)	CE128	Filtration, ICP-MS	U	0.03	mg/l K	Plastic		21 days
Selenium (dissolved)	CE128	Filtration, ICP-MS	U	0.07	µg/l Se	Plastic		28 days
Silver (dissolved)	CE128	Filtration, ICP-MS		0.2	µg/l Ag	Plastic		20 days
Sodium (dissolved)	CE128	Filtration, ICP-MS	U	0.6	mg/l Na	Plastic		10 days
Strontium (dissolved)	CE128	Filtration, ICP-MS	U	0.4	µg/l Sr	Plastic		28 days
Thallium (dissolved)	CE128	Filtration, ICP-MS		16	µg/l Tl	Plastic		7 days
Tin (dissolved)	CE128	Filtration, ICP-MS	U	0.5	µg/l Sn	Plastic		5 days
Titanium (dissolved)	CE128	Filtration, ICP-MS		2	µg/l Ti	Plastic		17 days
Vanadium (dissolved)	CE128	Filtration, ICP-MS	U	0.3	µg/l V	Plastic		12 days
Zinc (dissolved)	CE128	Filtration, ICP-MS	U	1	µg/l Zn	Plastic		3 days
Hardness (by calculation)	CE128	Filtration, ICP-MS		1	mg/l CaCO ₃	Plastic		20 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Aluminium (total)	CE218	Acid digestion, ICP-MS		4	µg/l Al	Plastic	pH <2 HNO ₃	28 days
Antimony (total)	CE218	Acid digestion, ICP-MS		0.1	µg/l Sb	Plastic	pH <2 HNO ₃	28 days
Arsenic (total)	CE218	Acid digestion, ICP-MS		0.06	µg/l As	Plastic	pH <2 HNO ₃	28 days
Barium (total)	CE218	Acid digestion, ICP-MS		0.6	µg/l Ba	Plastic	pH <2 HNO ₃	28 days
Beryllium (total)	CE218	Acid digestion, ICP-MS		0.06	µg/l Be	Plastic	pH <2 HNO ₃	28 days
Boron (total)	CE218	Acid digestion, ICP-MS		6	µg/l B	Plastic	pH <2 HNO ₃	28 days
Cadmium (total)	CE218	Acid digestion, ICP-MS		0.07	µg/l Cd	Plastic	pH <2 HNO ₃	28 days
Calcium (total)	CE218	Acid digestion, ICP-MS		0.04	mg/l Ca	Plastic	pH <2 HNO ₃	28 days
Chromium (total)	CE218	Acid digestion, ICP-MS		0.2	µg/l Cr	Plastic	pH <2 HNO ₃	28 days
Cobalt (total)	CE218	Acid digestion, ICP-MS		0.2	µg/l Co	Plastic	pH <2 HNO ₃	28 days
Copper (total)	CE218	Acid digestion, ICP-MS		0.4	µg/l Cu	Plastic	pH <2 HNO ₃	28 days
Iron (total)	CE218	Acid digestion, ICP-MS		3	µg/l Fe	Plastic	pH <2 HNO ₃	28 days
Lead (total)	CE218	Acid digestion, ICP-MS		0.2	µg/l Pb	Plastic	pH <2 HNO ₃	28 days
Magnesium (total)	CE218	Acid digestion, ICP-MS		0.01	mg/l Mg	Plastic	pH <2 HNO ₃	28 days
Manganese (total)	CE218	Acid digestion, ICP-MS		0.4	µg/l Mn	Plastic	pH <2 HNO ₃	28 days
Mercury (total)	CE218	Acid digestion, ICP-MS		0.008	µg/l Hg	Plastic	pH <2 HNO ₃	28 days
Molybdenum (total)	CE218	Acid digestion, ICP-MS		0.3	µg/l Mo	Plastic	pH <2 HNO ₃	28 days
Nickel (total)	CE218	Acid digestion, ICP-MS		0.5	µg/l Ni	Plastic	pH <2 HNO ₃	28 days
Phosphorus (total)	CE218	Acid digestion, ICP-MS		0.02	mg/l P	Plastic	pH <2 HNO ₃	28 days
Potassium (total)	CE218	Acid digestion, ICP-MS		0.03	mg/l K	Plastic	pH <2 HNO ₃	28 days
Selenium (total)	CE218	Acid digestion, ICP-MS		0.07	µg/l Se	Plastic	pH <2 HNO ₃	28 days
Sodium (total)	CE218	Acid digestion, ICP-MS		0.6	mg/l Na	Plastic	pH <2 HNO ₃	28 days
Strontium (total)	CE218	Acid digestion, ICP-MS		0.4	µg/l Sr	Plastic	pH <2 HNO ₃	28 days
Sulphur (total)	CE218	Acid digestion, ICP-MS		0.2	mg/l S	Plastic	pH <2 HNO ₃	28 days
Thallium (total)	CE218	Acid digestion, ICP-MS		16	µg/l Tl	Plastic	pH <2 HNO ₃	28 days
Tin (total)	CE218	Acid digestion, ICP-MS		0.5	µg/l Sn	Plastic	pH <2 HNO ₃	28 days
Titanium (total)	CE218	Acid digestion, ICP-MS		2	µg/l Ti	Plastic	pH <2 HNO ₃	28 days
Vanadium (total)	CE218	Acid digestion, ICP-MS		0.3	µg/l V	Plastic	pH <2 HNO ₃	28 days
Zinc (total)	CE218	Acid digestion, ICP-MS		1	µg/l Zn	Plastic	pH <2 HNO ₃	28 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Inorganics								
pH	CE213	Based on BS 1377, pH Meter	U	0.1	units	Plastic,Glass		7 days
Electrical conductivity	CE214	Conductivity Meter	U	10	µS/cm	Plastic,Glass		7 days
Redox Potential	CE082	ORP meter		±0.1	mV	Plastic,Glass		7 days
Ammonia	CE012	Colorimetry	U	10	µg/l N	Plastic,Glass		1 day
Ammonia	CE012	Colorimetry	U	10	µg/l N	Plastic,Glass	0.45µm filter, pH <2 H ₂ SO ₄	21 days
Ammoniacal Nitrogen	CE012	Colorimetry	U	10	µg/l NH ₄	Plastic,Glass		1 day
Ammoniacal Nitrogen	CE012	Colorimetry	U	10	µg/l NH ₄	Plastic,Glass	0.45µm filter, pH <2 H ₂ SO ₄	21 days
Bromate	CE219	Ion Chromatography		0.7	mg/l BrO ₃	Plastic,Glass		28 days
Bromide	CE049	Ion Chromatography	U	0.4	mg/l Br	Plastic,Glass		28 days
Chloride	CE049	Ion Chromatography	U	0.5	mg/l Cl	Plastic,Glass		28 days
Fluoride	CE049	Ion Chromatography	U	0.1	mg/l F	Plastic,Glass		28 days
Nitrate	CE049	Ion Chromatography	U	0.3	mg/l NO ₃	Plastic,Glass		1 day
Nitrite	CE049	Ion Chromatography	U	0.2	mg/l NO ₂	Plastic,Glass		1 day
Total Oxidised Nitrogen (as N)	CE049	Sum of Nitrate and Nitrite		0.2	mg/l N	Plastic,Glass		1 day
Phosphate	CE049	Ion Chromatography	U	0.3	mg/l PO ₄	Plastic,Glass		2 days
Sulphate	CE049	Ion Chromatography	U	1.7	mg/l SO ₄	Plastic,Glass		28 days
Sulphur (free)	CE034	Solvent extraction, HPLC		5	mg/l S	Plastic,Glass		28 days
Sulphur (dissolved)	CE128	ICP-MS	U	0.2	mg/l S	Plastic,Glass		28 days
Sulphide	CE220	Continuous Flow Colorimetry		0.1	µg/l S ²⁻	Plastic,Glass		7 days
Cyanide (free)	CE147	Continuous Flow Colorimetry		20	µg/l CN	Plastic (dark)	pH >12 NaOH	7 days
Cyanide (complex)	CE147	Calculation: CN (total) - CN (free)		20	µg/l CN	Plastic (dark)	pH >12 NaOH	7 days
Cyanide (total)	CE147	Continuous Flow Colorimetry		20	µg/l CN	Plastic (dark)	pH >12 NaOH	14 days
Thiocyanate	CE014	Colorimetry	U	200	µg/l SCN	Plastic (dark)	pH >12 NaOH	7 days
Phenols (total)	CE148	Continuous Flow Colorimetry		10	µg/l PhOH	Glass		21 days
Alkalinity (settled)	CE035	Titrimetry	U	2	mg/l CaCO ₃	Plastic,Glass		14 days
Suspended solids	CE038	Gravimetry	U	2	mg/l	Plastic,Glass		7 days
Total dissolved solids	CE039	TDS meter		10	mg/l TDS	Plastic,Glass		28 days
Total solids	CE091	Gravimetry		10	mg/l	Plastic,Glass		7 days
Biological Oxygen Demand	CE036	5 day ATU, DO Meter		1	mg/l O ₂	Plastic,Glass		2 days
Chemical Oxygen Demand (filtered)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass		28 days
Chemical Oxygen Demand (filtered)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass	0.45µm filter, pH <2 H ₂ SO ₄	180 days
Chemical Oxygen Demand (settled)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass		5 days
Chemical Oxygen Demand (total)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass		5 days
Chemical Oxygen Demand (total)	CE037	Colorimetry	U	10	mg/l O ₂	Plastic,Glass	pH <2 H ₂ SO ₄	180 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited
\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Inorganics (cont)								
Dissolved Oxygen	CE040	DO meter		1	mg/l O ₂	Plastic,Glass	Determine in-situ	In-situ
Dissolved Organic Carbon	CE071	Filtration, TOC analyser		5	mg/l C	Vial		7 days
Total Organic Carbon	CE071	TOC analyser		5	mg/l C	Vial		7 days
Oil & Grease	CE030	Solvent extraction, Gravimetry		1	mg/l	Glass	pH <2 H ₂ SO ₄	28 days
Detergents	CE221	Colorimetry		1	mg/l MBAS	Glass	pH <2 H ₂ SO ₄	2 days
Nitrogen (total)	CE086	Nitrogen analyser		0.1	mg/l	Plastic,Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PAHs								
Naphthalene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Acenaphthylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Acenaphthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Fluorene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Phenanthrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(a)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Chrysene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(b)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(k)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(a)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Indeno(123cd)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Dibenz(ah)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(ghi)perylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PAH (total of USEPA 16)	CE051	Solvent extraction, GC-MS		1.6	µg/l	Glass		7 days
Benzo(j)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PAH (total of OIL 8)	CE051	Solvent extraction, GC-MS		0.8	µg/l	Glass		7 days
Coronene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PAH (total of 17)	CE051	Solvent extraction, GC-MS		1.7	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited
\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PAHs (low level)								
Naphthalene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Acenaphthylene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Acenaphthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Fluorene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Phenanthrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Benzo(a)anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Chrysene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Benzo(b)fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Benzo(k)fluoranthene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Benzo(a)pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Indeno(123cd)pyrene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Dibenz(ah)anthracene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
Benzo(ghi)perylene	CE196	Solvent extraction, GC-MS (low level)		0.01	µg/l	Glass		7 days
PAH (total of USEPA 16)	CE196	Solvent extraction, GC-MS (low level)		0.17	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Banded								
VPH (>C5-C10)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH (>C5-C7)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH (>C7-C8)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH (>C8-C10)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
EPH (>C10-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C44)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C16)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C16-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C20)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C20-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C21)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C21-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C25)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C25-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C28)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C28-C40)	CE052	Solvent extraction, GC-FID		10	µg/l	Glass		7 days
EPH (>C10-C12)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C12-C16)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C16-C21)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C16-C35)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C21-C35)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C35-C40)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH (>C35-C44)	CE052	Solvent extraction, GC-FID		1	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
TPH Aliphatic/Aromatic								
VPH Aliphatic (>C5-C6)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH Aliphatic (>C6-C8)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH Aliphatic (>C8-C10)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH Aromatic (>EC5-EC7)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH Aromatic (>EC7-EC8)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
VPH Aromatic (>EC8-EC10)	CE175	Headspace GC-FID		1	µg/l	Vial	Fill to brim, no headspace	7 days
EPH Aliphatic (>C10-C12)	CE161	Solvent extraction, GC-FID		1	µg/l	Vial		7 days
EPH Aliphatic (>C12-C16)	CE161	Solvent extraction, GC-FID		1	µg/l	Vial		7 days
EPH Aliphatic (>C16-C21)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aliphatic (>C16-C35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aliphatic (>C21-C35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aliphatic (>C35-C44)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aromatic (>EC10-EC12)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aromatic (>EC12-EC16)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aromatic (>EC16-EC21)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aromatic (>EC21-EC35)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days
EPH Aromatic (>EC35-EC44)	CE161	Solvent extraction, GC-FID		1	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds								
MTBE	CE057	Headspace GC-FID	U	2	µg/l	Vial	Fill to brim, no headspace	7 days
Benzene	CE057	Headspace GC-FID	U	1	µg/l	Vial	Fill to brim, no headspace	7 days
Toluene	CE057	Headspace GC-FID	U	1	µg/l	Vial	Fill to brim, no headspace	7 days
Ethylbenzene	CE057	Headspace GC-FID	U	1	µg/l	Vial	Fill to brim, no headspace	7 days
m & p-Xylene	CE057	Headspace GC-FID	U	2	µg/l	Vial	Fill to brim, no headspace	7 days
o-Xylene	CE057	Headspace GC-FID	U	1	µg/l	Vial	Fill to brim, no headspace	7 days
Dichlorodifluoromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Chloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Vinyl chloride	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Bromomethane	CE066	Headspace GC-MS		3	µg/l	Vial	Fill to brim, no headspace	7 days
Chloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Trichlorofluoromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Trans-1,2-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1-Dichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
2,2-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Cis-1,2-Dichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Bromochloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Chloroform	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1,1-Trichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Carbon tetrachloride	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2-Dichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Trichloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Dibromomethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Bromodichloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
cis-1,3-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
trans-1,3-Dichloro-1-propene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1,2-Trichloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited
\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Volatile Organic Compounds (cont)								
Tetrachloroethene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,3-Dichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Dibromochloromethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2-Dibromoethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Chlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1,1,2-Tetrachloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Styrene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Tribromomethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Isopropylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Bromobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,1,2,2-Tetrachloroethane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2,3-Trichloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Propylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
2-Chlorotoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
4-Chlorotoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,3,5-Trimethylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
tert-Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2,4-Trimethylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
sec-Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,3-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
4-Isopropyltoluene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,4-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2-Dichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Butylbenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2-Dibromo-3-chloropropane	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2,4-Trichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
Hexachloro-1,3-butadiene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
1,2,3-Trichlorobenzene	CE066	Headspace GC-MS		1	µg/l	Vial	Fill to brim, no headspace	7 days
VOC Tentatively Identified Compounds	CE066	Headspace GC-MS		10	µg/l	Vial	Fill to brim, no headspace	7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds								
Naphthalene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Acenaphthylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Acenaphthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Fluorene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Phenanthrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(a)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Chrysene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(b)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(k)fluoranthene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(a)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Indeno(123cd)pyrene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Dibenz(ah)anthracene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Benzo(ghi)perylene	CE051	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
N-Nitrosodimethylamine	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Phenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Bis(2-chloroethyl)ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Chlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
1,3-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
1,4-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
1,2-Dichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Bis(2-chloroisopropyl)ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
3&4-Methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
N-Nitrosodi-n-propylamine	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Hexachloroethane	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Nitrobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Isophorone	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,4-Dimethylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Nitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Bis(2-chloroethoxy)methane	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Semi-volatile Organic Compounds (cont)								
2,4-Dichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
1,2,4-Trichlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Chloroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Hexachlorobutadiene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Chloro-3-methylphenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Methylnaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
1-Methylnaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Hexachlorocyclopentadiene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,4,6-Trichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,4,5-Trichlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Chloronaphthalene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Dimethyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,6-Dinitrotoluene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
3-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,4-Dinitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Nitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2,4-Dinitrotoluene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Dibenzofuran	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Diethyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Chlorophenylphenyl ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Nitroaniline	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
2-Methyl-4,6-dinitrophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Azobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
4-Bromophenylphenyl ether	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Hexachlorobenzene	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Pentachlorophenol	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Carbazole	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Di-n-butyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Butylbenzyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Bis(2-ethylhexyl)phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
Di-n-octyl phthalate	CE065	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
SVOC Tentatively Identified Compounds	CE065	Solvent extraction, GC-MS		1	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Phenols (speciated)								
Dimethylphenols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Methylphenols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Naphthols	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Phenol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Trimethylphenol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Catechol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
Resorcinol	CE065	Solvent extraction, GCMS		0.1	µg/l	Glass		21 days
PCB (ICES 7)								
PCB Congener 28	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 52	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 101	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 118	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 138	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 153	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 180	CE070	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB (total of ICES 7)	CE070	Solvent extraction, GC-MS		0.7	µg/l	Glass		7 days
PCB (WHO 12)								
PCB Congener 77	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 81	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 105	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 114	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 118	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 123	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 126	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 156	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 157	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 167	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 169	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB Congener 189	CE187	Solvent extraction, GC-MS		0.1	µg/l	Glass		7 days
PCB (total of WHO 12)	CE187	Solvent extraction, GC-MS		1.2	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides								
2,4'-DDD (O,P'-DDD)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDD (P,P'-DDD)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4'-DDE (O,P'-DDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDE (P,P'-DDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4'-DDT (O,P'-DDT)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-DDT (P,P'-DDT)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-TDE (P,P'-TDE)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,6-Dichlorobenzonitrile	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4,4'-Dichlorobenzophenone	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Aldrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Alpha-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Benfluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Beta-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Biphenyl	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorfenson	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chloroneb	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorothalonil	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
cis-Chlordane	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
cis-Nonachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Delta-HCH	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlofluanid	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicloran	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicofol	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dieldrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Diphenylamine	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan A	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan B	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan ether	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endosulphan sulphate	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin aldehyde	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Endrin ketone	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organochlorine pesticides (cont)								
Ethalfuralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenson	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Gamma-HCH (Lindane)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
HCB	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Heptachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Heptachlor epoxide	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isodrin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isopropalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isopropalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methoxychlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methoxychlor olefin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Mirex	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Nitralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Nitrofen	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Oxyfluorfen	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pendimethalin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloroaniline	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloroanisole	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorobenzene	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorobenzonitrile	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachloronitrobenzene (Quintozone)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorothioanisole	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prodiamine	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Profluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tetrachloronitrobenzene (Tecnazene)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tetradifon	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
THPI (Tetrahydrophthalimide)	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tolyfluamid	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
trans-Chordane	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
trans-Nonachlor	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trifluralin	CE215	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides								
Acephate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Azinphos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Azinphos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bromophos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorpyrifos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chlorpyrifos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Coumaphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Demeton-S-methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Diazinon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlorvos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dimethoate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Disulfoton	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
EPN	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ethion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ethoprophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Famphur	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenchlorphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fenitrothion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fensulfothion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Isazophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Malathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Merphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methamidophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methidathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Methomyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Monocrotophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Naled	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Omethoate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Parathion	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Parathion methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phorate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS



Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited
\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organophosphate pesticides (cont)								
Phosalone	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phosmet	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pirimiphos ethyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pirimiphos methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Profenofos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prothiophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyraclufos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyrazophos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pyridaphention	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Quinalphos	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Sulfotep	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Thiofanox	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Thionazin	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Tolclofos-methyl	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trichlorfon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Trichlorfon	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Triethyl thiophosphate	CE216	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Acid herbicides								
2,4-D	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4,5-T	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4-DB	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Acifluorfen	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bentazon	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Bromoxynil	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Chloramben	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dalapon	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dicamba	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
3,5-Dichlorobenzoic acid (DBA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dichlorprop (2,4-DP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Dinoseb (DNBP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,4,5-TP	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Fluroxypyr	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Imazapyr	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Ioxynil	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
MCPA	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
MCPP	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Mecoprop (MCP)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Pentachlorophenol	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Picloram	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
2,3,6-TBA	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
4-Chlorophenoxyacetic acid (4-CPA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxyacetic acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxybutyric acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Phenoxypropionic acid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Propanil (DCPA)	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
DCPA diacid	CE217	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days

TECHNICAL DETAILS SUMMARY

WATERS

Further method details are available on request.

UKAS accreditation for waters applies to effluents, groundwaters, landfill leachates, and surface waters.

Key: U = UKAS accredited

\$ = Subcontracted

WATERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Organonitrogen pesticides								
Ametryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Atraton	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Atrazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prometon	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Prometryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Propazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Secbumbeton	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Simazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Simetryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Terbutylazine	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Terbutryn	CE210	Solvent extraction, GC-MS		0.01	µg/l	Glass		7 days
Subcontracted testing								
Microbiology (natural)		Details on request	U	1	colonies/ml	Plastic		1 day
Microbiology (chlorinated)		Details on request	U	1	colonies/ml	Plastic	Na ₂ S ₂ O ₃	1 day
Legionella		Based on BS 6068-4.12:1998; ISO 11731:1998	U	100	colonies/l	Plastic (dark)	Na ₂ S ₂ O ₃ , room temp	1 day
Dibutyl tin	\$	Extraction, GC-MS		0.1	µg/l	Glass		*14 days
Tributyl tin	\$	Extraction, GC-MS		0.1	µg/l	Glass		*14 days
Triphenyl tin	\$	Extraction, GC-MS		0.1	µg/l	Glass		*14 days
Perfluorooctyl sulphonate (PFOS)*	\$	LC-MS		0.1	µg/l	Plastic		*14 days
Perfluorooctanoic acid (PFOA)*	\$	LC-MS		0.1	µg/l	Plastic		*14 days

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

ROAD CORES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Preparation								
Core Sample Preparation	CE001	Preparation only	-	-	-	-	-	N/A
Phenols (speciated)								
Dimethylphenols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Methylphenols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Naphthols	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Phenol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Trimethylphenol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Catechol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Resorcinol	CE189	Solvent extraction, GCMS		0.1	mg/kg	Glass		N/A
Phenols (total)	CE184	Extraction, Continuous Flow Colorimetry		0.5	mg/kg	Plastic,Glass		N/A
PAHs								
Naphthalene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Acenaphthylene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Acenaphthene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Fluorene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Phenanthrene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Anthracene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Fluoranthene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Pyrene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Benzo(a)anthracene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Chrysene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Benzo(b)fluoranthene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Benzo(k)fluoranthene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Benzo(a)pyrene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Indeno(123cd)pyrene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Dibenz(ah)anthracene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
Benzo(ghi)perylene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
PAH (total of USEPA 16)	CE151	Solvent extraction, GC-MS		16	mg/kg	Plastic,Glass		N/A
Coronene	CE151	Solvent extraction, GC-MS		1	mg/kg	Plastic,Glass		N/A
PAH (total of 17)	CE151	Solvent extraction, GC-MS		17	mg/kg	Plastic,Glass		N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

FILTERS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Aluminium (total)	CE074	Acid digestion, ICP-MS		1	µg Al	Plastic,Glass		N/A
Antimony (total)	CE074	Acid digestion, ICP-MS		1	µg Sb	Plastic,Glass		N/A
Arsenic (total)	CE074	Acid digestion, ICP-MS		1	µg As	Plastic,Glass		N/A
Barium (total)	CE074	Acid digestion, ICP-MS		1	µg Ba	Plastic,Glass		N/A
Cadmium (total)	CE074	Acid digestion, ICP-MS		1	µg Cd	Plastic,Glass		N/A
Calcium (total)	CE074	Acid digestion, ICP-MS		1	µg Ca	Plastic,Glass		N/A
Chromium (total)	CE074	Acid digestion, ICP-MS		1	µg Cr	Plastic,Glass		N/A
Chromium (VI)	CE110	Extraction, Colorimetry		1	µg CrVI	Plastic,Glass		N/A
Cobalt (total)	CE074	Acid digestion, ICP-MS		1	µg Co	Plastic,Glass		N/A
Copper (total)	CE074	Acid digestion, ICP-MS		1	µg Cu	Plastic,Glass		N/A
Iron (total)	CE074	Acid digestion, ICP-MS		1	µg Fe	Plastic,Glass		N/A
Lead (total)	CE074	Acid digestion, ICP-MS		1	µg Pb	Plastic,Glass		N/A
Manganese (total)	CE074	Acid digestion, ICP-MS		1	µg Mn	Plastic,Glass		N/A
Mercury (total)	CE074	Acid digestion, ICP-MS		1	µg Hg	Plastic,Glass		N/A
Molybdenum (total)	CE074	Acid digestion, ICP-MS		1	µg Mo	Plastic,Glass		N/A
Nickel (total)	CE074	Acid digestion, ICP-MS		1	µg Ni	Plastic,Glass		N/A
Selenium (total)	CE074	Acid digestion, ICP-MS		1	µg Se	Plastic,Glass		N/A
Zinc (total)	CE074	Acid digestion, ICP-MS		1	µg Zn	Plastic,Glass		N/A
Organics								
Formaldehyde	CE076	Extraction, Colorimetry		5	µg	Plastic,Glass		N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS

Further method details are available on request.

Key: \$ = Subcontracted

PAINTS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Arsenic (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Cadmium (total)	CE080	Aqua regia digest, ICP-MS		0.2	mg/kg	Plastic,Glass		N/A
Chromium (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Chromium (VI)	CE110	Extraction, Colorimetry		1	mg/kg	Plastic,Glass		N/A
Copper (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Lead (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Mercury (total)	CE080	Aqua regia digest, ICP-MS		0.5	mg/kg	Plastic,Glass		N/A
Nickel (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Selenium (total)	CE080	Aqua regia digest, ICP-MS		0.3	mg/kg	Plastic,Glass		N/A
Zinc (total)	CE080	Aqua regia digest, ICP-MS		5	mg/kg	Plastic,Glass		N/A
Subcontracted testing								
Dibutyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Tributyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Triphenyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Plastic,Glass		N/A
Perfluorooctanoic acid (PFOA)	\$	LC-MS		1.0	µg/kg	Plastic,Glass		N/A
FOAMS								
Ozone Depleting Substances								
CFCs (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Halons (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Carbon tetrachloride	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
1,1,1-Trichloroethane	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
HCFC (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
HBFC (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Methyl bromide	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Bromochloromethane	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS

Further method details are available on request.

Key: \$ = Subcontracted

OILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PCB (ICES 7)								
PCB Congener 28	CE191	Solvent extraction, GC-MS		0.16	mg/kg	Glass		N/A
PCB Congener 52	CE191	Solvent extraction, GC-MS		0.16	mg/kg	Glass		N/A
PCB Congener 101	CE191	Solvent extraction, GC-MS		0.32	mg/kg	Glass		N/A
PCB Congener 118	CE191	Solvent extraction, GC-MS		0.24	mg/kg	Glass		N/A
PCB Congener 138	CE191	Solvent extraction, GC-MS		0.24	mg/kg	Glass		N/A
PCB Congener 153	CE191	Solvent extraction, GC-MS		0.36	mg/kg	Glass		N/A
PCB Congener 180	CE191	Solvent extraction, GC-MS		0.32	mg/kg	Glass		N/A
PCB (total of ICES 7)	CE191	Solvent extraction, GC-MS		1.8	mg/kg	Glass		N/A
Subcontracted testing								
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Glass		N/A

SOLIDS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PCB (ICES 7)								
PCB Congener 28	CE185	Solvent extraction, GC-MS		0.16	mg/kg	Plastic,Glass		N/A
PCB Congener 52	CE185	Solvent extraction, GC-MS		0.16	mg/kg	Plastic,Glass		N/A
PCB Congener 101	CE185	Solvent extraction, GC-MS		0.32	mg/kg	Plastic,Glass		N/A
PCB Congener 118	CE185	Solvent extraction, GC-MS		0.24	mg/kg	Plastic,Glass		N/A
PCB Congener 138	CE185	Solvent extraction, GC-MS		0.24	mg/kg	Plastic,Glass		N/A
PCB Congener 153	CE185	Solvent extraction, GC-MS		0.36	mg/kg	Plastic,Glass		N/A
PCB Congener 180	CE185	Solvent extraction, GC-MS		0.32	mg/kg	Plastic,Glass		N/A
PCB (total of ICES 7)	CE185	Solvent extraction, GC-MS		1.80	mg/kg	Plastic,Glass		N/A
Subcontracted testing								
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Plastic,Glass		N/A
Perfluorooctanoic acid (PFOA)	\$	LC-MS		1.0	µg/kg	Plastic,Glass		N/A

SWABS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PCB (ICES 7)								
PCB Congener 28	CE186	Solvent extraction, GC-MS		0.016	mg/kg	Glass		N/A
PCB Congener 52	CE186	Solvent extraction, GC-MS		0.016	mg/kg	Glass		N/A
PCB Congener 101	CE186	Solvent extraction, GC-MS		0.032	mg/kg	Glass		N/A
PCB Congener 118	CE186	Solvent extraction, GC-MS		0.024	mg/kg	Glass		N/A
PCB Congener 138	CE186	Solvent extraction, GC-MS		0.024	mg/kg	Glass		N/A
PCB Congener 153	CE186	Solvent extraction, GC-MS		0.036	mg/kg	Glass		N/A
PCB Congener 180	CE186	Solvent extraction, GC-MS		0.032	mg/kg	Glass		N/A
PCB (total of ICES 7)	CE186	Solvent extraction, GC-MS		0.180	mg/kg	Glass		N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

FOAMS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Ozone Depleting Substances								
CFCs	CE182	Headspace GC-MS		0.01	% w/w	Plastic,Glass	Minimise headspace	N/A
CFCs (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Halons (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Carbon tetrachloride	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
1,1,1-Trichloroethane	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
HCFC (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
HBFC (total)	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Methyl bromide	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A
Bromochloromethane	CE182	Headspace GC-MS		1	mg/kg	Plastic,Glass	Minimise headspace	N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

WASTE	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Loss On Ignition at 440°C	CE150	HMRC LFT1 : Combustion, Gravimetry		0.1	% w/w	Plastic,Glass	-	N/A

CONCRETE	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Chloride (total)	CE142	Based on BS1881-124		0.05	% w/w	Plastic,Glass	-	N/A
Cement content	CE167	Based on BS1881-124		0.01	% w/w	Plastic,Glass	-	N/A
Sulphate (total)	CE164	Based on BS1881-124		0.01	% w/w	Plastic,Glass	-	N/A

SOLIDS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PCB (ICES 7)								
PCB Congener 28	CE185	Solvent extraction, GC-MS		0.16	mg/kg	Plastic,Glass		N/A
PCB Congener 52	CE185	Solvent extraction, GC-MS		0.16	mg/kg	Plastic,Glass		N/A
PCB Congener 101	CE185	Solvent extraction, GC-MS		0.32	mg/kg	Plastic,Glass		N/A
PCB Congener 118	CE185	Solvent extraction, GC-MS		0.24	mg/kg	Plastic,Glass		N/A
PCB Congener 138	CE185	Solvent extraction, GC-MS		0.24	mg/kg	Plastic,Glass		N/A
PCB Congener 153	CE185	Solvent extraction, GC-MS		0.36	mg/kg	Plastic,Glass		N/A
PCB Congener 180	CE185	Solvent extraction, GC-MS		0.32	mg/kg	Plastic,Glass		N/A
PCB (total of ICES 7)	CE185	Solvent extraction, GC-MS		1.80	mg/kg	Plastic,Glass		N/A
Subcontracted testing								
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Glass		N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

PAINTS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Metals								
Lead (total)	CE080	Aqua regia digest, ICP-MS		0.01	% w/w Pb	Plastic,Glass		N/A
Arsenic (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Cadmium (total)	CE080	Aqua regia digest, ICP-MS		0.2	mg/kg	Plastic,Glass		N/A
Chromium (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Chromium (VI)	CE110	Extraction, Colorimetry		1	mg/kg	Plastic,Glass		N/A
Copper (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Lead (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Mercury (total)	CE080	Aqua regia digest, ICP-MS		0.5	mg/kg	Plastic,Glass		N/A
Nickel (total)	CE080	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Selenium (total)	CE080	Aqua regia digest, ICP-MS		0.3	mg/kg	Plastic,Glass		N/A
Zinc (total)	CE080	Aqua regia digest, ICP-MS		5	mg/kg	Plastic,Glass		N/A
Subcontracted testing								
Dibutyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Tributyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Triphenyltin	\$	GC-MS		0.1	µg/kg	Plastic,Glass		N/A
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Plastic,Glass		N/A
Perfluorooctanoic acid (PFOA)	\$	LC-MS		1.0	µg/kg	Plastic,Glass		N/A

TECHNICAL DETAILS SUMMARY

MISCELLANEOUS



Further method details are available on request.

Key: \$ = Subcontracted

OILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
PCB (ICES 7)								
PCB Congener 28	CE191	Solvent extraction, GC-MS		0.16	mg/kg	Glass		N/A
PCB Congener 52	CE191	Solvent extraction, GC-MS		0.16	mg/kg	Glass		N/A
PCB Congener 101	CE191	Solvent extraction, GC-MS		0.32	mg/kg	Glass		N/A
PCB Congener 118	CE191	Solvent extraction, GC-MS		0.24	mg/kg	Glass		N/A
PCB Congener 138	CE191	Solvent extraction, GC-MS		0.24	mg/kg	Glass		N/A
PCB Congener 153	CE191	Solvent extraction, GC-MS		0.36	mg/kg	Glass		N/A
PCB Congener 180	CE191	Solvent extraction, GC-MS		0.32	mg/kg	Glass		N/A
PCB (total of ICES 7)	CE191	Solvent extraction, GC-MS		1.8	mg/kg	Glass		N/A
Subcontracted testing								
Perfluorooctyl sulphonate (PFOS)	\$	LC-MS		0.1	µg/kg	Glass		N/A

TECHNICAL DETAILS SUMMARY

BS3882(2015) BS8061(2013)



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted

BS3882: SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Soil Texture	-	Soil classification	-	-	-	Plastic,Glass		-
Stone Content	-	Sieving	-	0.1	mg/kg	Plastic,Glass		-
Loss On Ignition at 440°C	CE006	Based on BS 1377, Gravimetry	U	0.1	% w/w	Plastic,Glass		28 days
pH	CE004	Based on BS 1377, pH Meter	M	-	units	Plastic,Glass		21 days
Carbonate (by difference)	CE072	Carbon Analyser, calculation TC-TOC		0.1	% w/w	Plastic,Glass		28 days
Nitrogen (total)	CE198	Combustion, Nitrogen analyser		0.01	% w/w	Plastic,Glass		28 days
Carbon:Nitrogen ratio	CE222	Calculation: TOC/Nitrogen (total)		0.1	-	Plastic,Glass		28 days
Phosphorus (extractable)	CE089	Sodium bicarbonate extraction, ICP-MS		1	mg/l	Plastic,Glass		28 days
Potassium (extractable)	CE088	Ammonium Nitrate, ICP-MS		1	mg/l	Plastic,Glass		28 days
Magnesium (extractable)	CE088	Ammonium Nitrate, ICP-MS		1	mg/l	Plastic,Glass		28 days
Sodium (extractable)	CE088	Ammonium Nitrate, ICP-MS		0.1	%	Plastic,Glass		28 days
Electrical conductivity	CE007	Conductivity Meter	U	10	µS/cm	Plastic,Glass		28 days
Copper (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Nickel (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Zinc (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		5	mg/kg	Plastic,Glass		180 days
Visible contaminants	-	Visual inspection, gravimetry		0.1	% w/w	Plastic,Glass		-

BS8061:2013 SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Soil Texture	-	Soil classification	-	-	-	Plastic,Glass		-
Stone Content	-	Sieving	-	0.1	mg/kg	Plastic,Glass		-
Copper (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Nickel (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		1	mg/kg	Plastic,Glass		180 days
Zinc (nitric acid extractable)	CE127	Nitric acid digest, ICP-MS		5	mg/kg	Plastic,Glass		180 days
Sodium (extractable)	CE088	Ammonium Nitrate, ICP-MS		0.1	%	Plastic,Glass		28 days
pH	CE004	Based on BS 1377, pH Meter	M	-	units	Plastic,Glass		21 days
Electrical conductivity	CE007	Conductivity Meter	U	10	µS/cm	Plastic,Glass		28 days
Loss On Ignition at 440°C	CE006	Based on BS 1377, Gravimetry	U	0.1	% w/w	Plastic,Glass		28 days

TECHNICAL DETAILS SUMMARY TEST SUITES



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

UKWIR: SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
VPH (>C5-C10)	CE067	Headspace GC-FID		0.1	mg/kg	VOC jar	Fill to brim, no headspace	14 days
EPH (>C10-C16)	CE033	Solvent extraction, GC-FID		10	mg/kg	Glass		*14 days
EPH (>C16-C40)	CE033	Solvent extraction, GC-FID		10	mg/kg	Glass		*14 days
EPH (>C10-C20)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
EPH (>C20-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*14 days
VOC (total) inc TICs	CE066	Headspace GC-MS		0.01	mg/kg	VOC jar	Fill to brim, no headspace	14 days
BTEX & MTBE (total)	CE057	Headspace GC-FID		0.06	mg/kg	VOC jar	Fill to brim, no headspace	14 days
SVOC (total) inc TICs	CE065	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Phenols (total)	CE065	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Cresols & chlorinated phenols (total)	CE065	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Ethers*	CE065	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Nitrobenzene*	CE065	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
Ketones*	CE065	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Aldehydes*	CE065	Solvent extraction, GC-MS		0.01	mg/kg	Glass		*14 days
Amines*	CE065	Solvent extraction, GC-MS		0.1	mg/kg	Glass		*14 days
pH	CE004	Based on BS 1377, pH Meter	M	-	units	Plastic,Glass		21 days
Electrical conductivity	CE007	Conductivity Meter	U	10	µS/cm	Plastic,Glass		28 days
Redox potential	CE082	ORP meter		±1	% w/w	Plastic,Glass		28 days

TECHNICAL DETAILS SUMMARY

WAC TESTING

Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

WAC: SOILS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Antimony (total)	CE127	Aqua regia digest, ICP-MS	M	0.2	mg/kg	Plastic,Glass		180 days
Arsenic (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Barium (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Cadmium (total)	CE127	Aqua regia digest, ICP-MS	M	0.2	mg/kg	Plastic,Glass		180 days
Chromium (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Copper (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Lead (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Mercury (total)	CE127	Aqua regia digest, ICP-MS	M	0.5	mg/kg	Plastic,Glass		180 days
Molybdenum (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Nickel (total)	CE127	Aqua regia digest, ICP-MS	M	1	mg/kg	Plastic,Glass		180 days
Selenium (total)	CE127	Aqua regia digest, ICP-MS	M	0.3	mg/kg	Plastic,Glass		180 days
Zinc (total)	CE127	Aqua regia digest, ICP-MS	M	5	mg/kg	Plastic,Glass		180 days
pH	CE004	Based on BS 1377, pH Meter	M	-	units	Plastic,Glass		21 days
Acid Neutralising Capacity	CE083	Titration		0.01	mol/kg	Plastic,Glass		28 days
Total Organic Carbon	CE072	Removal of IC by acidification, Carbon Analyser	M	0.1	% w/w	Plastic,Glass		28 days
Loss On Ignition at 440°C	CE006	Based on BS 1377, Gravimetry	U	0.1	% w/w	Plastic,Glass		28 days
PAH (total of 17)	CE087	Solvent extraction, GC-MS		0.36	mg/kg	Glass		*14 days
BTEX (total)	CE057	Headspace GC-FID	U	0.06	mg/kg	VOC jar	Fill to brim, no headspace	14 days
EPH (>C10-C40)	CE033	Solvent extraction, GC-FID	M	10	mg/kg	Glass		*28 days
PCB (total of ICES 7)	CE137	Solvent extraction, GC-MS	M	0.045	mg/kg	Glass		*14 days

TECHNICAL DETAILS SUMMARY

WAC TESTING



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key: M = MCERTS accredited
U = UKAS accredited

\$ = Subcontracted
*days for extraction; 40 days after extraction for analysis.

WAC: SOLIDS	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Antimony (total)	CE127	Aqua regia digest, ICP-MS		0.2	mg/kg	Plastic,Glass		N/A
Arsenic (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Barium (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Cadmium (total)	CE127	Aqua regia digest, ICP-MS		0.2	mg/kg	Plastic,Glass		N/A
Chromium (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Copper (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Lead (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Mercury (total)	CE127	Aqua regia digest, ICP-MS		0.5	mg/kg	Plastic,Glass		N/A
Molybdenum (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Nickel (total)	CE127	Aqua regia digest, ICP-MS		1	mg/kg	Plastic,Glass		N/A
Selenium (total)	CE127	Aqua regia digest, ICP-MS		0.3	mg/kg	Plastic,Glass		N/A
Zinc (total)	CE127	Aqua regia digest, ICP-MS		5	mg/kg	Plastic,Glass		N/A
pH	CE004	Based on BS 1377, pH Meter		-	units	Plastic,Glass		N/A
Acid Neutralising Capacity	CE083	Titration		0.01	mol/kg	Plastic,Glass		N/A
Total Organic Carbon	CE072	Removal of IC by acidification, Carbon Analyser		0.1	% w/w	Plastic,Glass		N/A
Loss On Ignition at 440°C	CE006	Based on BS 1377, Gravimetry		0.1	% w/w	Plastic,Glass		N/A
PAH (total of 17)	CE087	Solvent extraction, GC-MS		0.36	mg/kg	Glass		N/A
BTEX (total)	CE057	Headspace GC-FID		0.06	mg/kg	Glass		N/A
EPH (>C10-C40)	CE033	Solvent extraction, GC-FID		10	mg/kg	Glass		N/A
PCB (total of ICES 7)	CE137	Solvent extraction, GC-MS		0.045	mg/kg	Glass		N/A

TECHNICAL DETAILS SUMMARY

WAC TESTING



Further method details are available on request.

MCERTS (soils) applies to sand, clay and loam/topsoil matrices or combinations of these.

Key:

M = MCERTS accredited

\$ = Subcontracted

U = UKAS accredited

*days for extraction; 40 days after extraction for analysis.

WAC: PREPARED LEACHATES	METHOD	METHOD SUMMARY	STATUS	LOD	UNITS	CONTAINER	REQUIREMENTS	HOLDING TIME
Leachate preparation (single-stage)	CE002	BS12457-1 or BS12457-2		-	-	-	-	-
Leachate preparation (two-stage)	CE002	BS12457-3		-	-	-	-	-
Antimony (dissolved)	CE128	ICP-MS	U	0.1	µg/l Sb	Plastic		180 days
Arsenic (dissolved)	CE128	ICP-MS	U	0.06	µg/l As	Plastic		180 days
Barium (dissolved)	CE128	ICP-MS	U	0.6	µg/l Ba	Plastic		180 days
Cadmium (dissolved)	CE128	ICP-MS	U	0.07	µg/l Cd	Plastic		180 days
Chromium (dissolved)	CE128	ICP-MS	U	0.2	µg/l Cr	Plastic		180 days
Copper (dissolved)	CE128	ICP-MS	U	0.4	µg/l Cu	Plastic		180 days
Lead (dissolved)	CE128	ICP-MS	U	0.2	µg/l Pb	Plastic		180 days
Mercury (dissolved)	CE128	ICP-MS	U	0.008	µg/l Hg	Plastic		180 days
Molybdenum (dissolved)	CE128	ICP-MS	U	0.3	µg/l Mo	Plastic		180 days
Nickel (dissolved)	CE128	ICP-MS	U	0.5	µg/l Ni	Plastic		180 days
Selenium (dissolved)	CE128	ICP-MS	U	0.07	µg/l Se	Plastic		180 days
Zinc (dissolved)	CE128	ICP-MS	U	1	µg/l Zn	Plastic		180 days
pH	CE213	Based on BS 1377, pH Meter	U	-	units	Plastic,Glass		21 days
Electrical conductivity	CE214	Conductivity Meter	U	10	µS/cm	Plastic,Glass		21 days
Chloride	CE049	Ion Chromatography	U	1	mg/l	Plastic,Glass		28 days
Fluoride	CE049	Ion Chromatography	U	0.1	mg/l	Plastic,Glass		28 days
Sulphate	CE049	Ion Chromatography	U	10	mg/l	Plastic,Glass		28 days
Total dissolved solids	CE039	TDS meter		10	mg/l	Plastic,Glass		28 days
Dissolved Organic Carbon	CE071	Filtration, TOC analyser	U	1	mg/l	Plastic,Glass		28 days
Phenols (total)	CE148	Continuous Flow Colorimetry		0.01	mg/l	Plastic,Glass		28 days